



MAUSER S P E Z I A L

MPN: MA1245-6/01

Mauser Spezial (Pfaff) MA1245 6/01 CLPMN8 Walking Foot Needle Feed Industrial Upholstery Sewing Machine, 7/14mmLift HookOil TopBobbin KD Stand 2800SPM

*FREE Organ 134x35R PD Titanium Coated Needles 100/Box Size 20-24 Recommended for Upholstery Thread 69-207. Compare Reliable MSK1245 copy for 1/2 Pfaff 1245 price Delivered.

Our Price: \$1,999.00
or \$69.97/mo (with approved credit)
Found a lower price? [Let us know](#)

List Price: ~~\$2,999.00~~
~~Was: \$2,499.00~~

110V default	<input type="text" value="Please Choose"/>
Assembled	<input type="text" value="Please Choose"/>
Residential or Commercial	<input type="text" value="Please Choose"/>
Lift Gate Options	<input type="text" value="Please Choose"/>

Availability This item ships separately from other warehouses. Usually leaves the warehouse in 5-7 business days.

Condition New In Box

Returns Repair Only

Coupons [Sorry, no coupons can be accepted](#)

ALSO INCLUDES



INCLUDED: [Organ 134 35R PD Titanium Coat Industrial Sewing Machine Needles DPx35R SY7225 2134-35R, Box of 100, Pfaff 1245 Durkopp Adler Walking Foot and Bartack](#)

Choose Size

*KD Stand is Knocked Down un-assembled Table, Stand and Motor requiring your assembly after delivery. .

For sewing of medium to heavy materials, leather, canvas, vinyl, furniture and car upholstery, heavy leather clothing, leather goods, handbags, etc.

- Sews Up To 2800 Stitches Per Minute
- Unison Feed - Compound Walking Foot And Needle Feed
- Automatic Hook Lubrication
- Includes 1/2 Hp Motor And Power Stand 110v
- Upholstery Sewing Machine
- Needle system : 134-35R
- Available in 110V or 220
- *KD Knocked Down Unassembled Power Stand Requires Assembly

Note: On the 1st of August 2010, Pfaff Industrial Machinery (Taicang) Co., Ltd. was purchased by the Tribonia Int. GmbH Germany and is now operating under the name of the well known industrial sewing machine manufacturer MAUSER SPEZIAL. The 1245 & 335 models are now branded Mauser Spezial same machines , same quality and warranty.

- US Warranty 90 Days labor on defects in materials and workmanship.
- Non-US Warranty: 30 days parts and labor

Specifications

Technical data:

- Stitch type: 301 (lockstitch)
- Bedplate dimensions : 476 x 177 mm
- Net weight : (sewing head) approx. 36 kg, 79 pounds
- Gross Weight : (sewing head in carton) approx. 44 kg, 97 pounds
- Max speed: 2800SPM Stitches per Minute
- Top feed foot lift: 7 mm
- Fabric clearance by Knee Lifter: max. 14 mm
- Needle system: 134-35
- Needle size: (Nm in 1/100 mm): 110-140
- Balance wheel: 80 mm eff. diameter
- Motor power: 0.370 or 0.550 kW,
- Clear work space: 270 x 115 mm

- Sews up to 2800 stitches per minute depending on motor speed and pulley size
- High traction due to unison feet
- Even feed motion without any ply-shift of individual layers
- Large vertical rotary hook with 60% more bobbin thread capacity than any other standard-sized hooks
- Automatic hook lubrication
- Efficient hook protection due to standard built-in overload coupling
- Rugged and durable
- High top feed lift allows trouble-free sewing of thick materials and easy sewing over cross seams
- Easy to service
- Easy loading and unloading - even of bulky material - due to a high fabric clearance of 14 mm
- Extremely quiet running and ergonomic design
- Made to handle furniture, upholstery, drapes, and more
- Needle system : 134-35R
- Needle Size Information:
 - #207 top thread and #138 Bobbin thread use a #23/160 needle
 - #138 top thread and #138 Bobbin thread use a #22/140 needle
 - #92 top thread and a #92 or #69 bobbin thread use a #21/120 needle
 - #69 top thread and a #69 bobbin thread use a #20/110 needle

[Click here for instructions on industrial sewing machine power stand assembly only, if it is delivered to you knocked down and unassembled. Illustrations are for traditional clutch motors, but applicable to new dc servo motors.](#)

[Click here for instructions on power stand assembly for WALKING FOOT machines, if it is delivered to you knocked down and unassembled. Illustrations are for traditional clutch motors, but applicable to new dc servo motors.](#)

[Please review our Freight LTL Shipping Policies](#)
Ships Ground Freight only.

Included Accessories

- 20 X 42 inch deluxe solid plywood table
- Deluxe Pressed Steel Legs with table-top tilt feature and treadle
- Clutch Motor (Specify 110V or 220V)
- Motor Switch
- Drawer
- Sewing Light with Bulb
- V-Belt
- Assembly

Superior, NYC

Single welt cording piping foot set from 1/8-3/16-1/4". Generic Part Numbers Superior 91-049047 and 91-049544 for 1/4". Set is \$29.00
special order Double welt from 1/8-5/32-3/16-1/4-5/16-3/8". Set is \$29 special order from Superior.



[Industrial and Commercial Sewing Machine Accessories](#)



[PFAFF & Mauser Spezial Industrial Sewing Machines & Power Stand](#)



[Leather Vinyl Canvas Upholstery & Fur Sewing Machines](#)