



Item # _____

Job _____



SUPER ADJUSTABLE 2™ SUPER ERECTA SHELF®
Adjustable Wire Shelving

SUPER ADJUSTABLE 2™ SUPER ERECTA SHELF® WIRE SHELVING

Super Adjustable 2™ Super Erecta Wire Shelving is the most advanced and innovative wire storage system available. The unique Corner Release System, which allows shelves to be adjusted quickly and easily without tools, has been re-engineered to provide increased rigidity. And Super Adjustable 2™ Shelving works in conjunction with the entire Super Erecta System of shelves and accessories.

- **Maximum Space Utilization:** The Corner Release System encourages repositioning of shelves during initial assembly to reclaim wasted vertical space. In some cases, reclaimed vertical space will allow an extra shelving tier to be added to the storage unit resulting in a 25% increase in storage capacity!
- **Easily Assembled:** The unique Corner Release System enables quick and easy repositioning of shelves during the initial set up to accommodate different package or container sizes. "Total Assembly" is complete only after the shelves are properly spaced to maximize storage. SiteSelect™ Posts, with the double-groove visual guide feature, have circular grooves at 1" (25mm) increments and are numbered at 2" (51mm) intervals to easily identify proper shelf locations.
- **Easily Adjustable:** The unique shelf design and SiteSelect™ Posts enable "tool-free", quick adjustment at 1" (25mm) increments along the entire height of the post.
- **Improved Rigidity:** An enhanced Corner Release System has made Super Adjustable 2™ the most rigid, easily adjustable shelving system ever.
- **Strong:** Super Adjustable 2™ shelves hold as much weight as traditional Super Erecta wire shelving. Stationary units hold a maximum of 2,000 lb. (910kg). Maximum weight capacity per shelf (48" [1219mm] or shorter = 800 lb. [364kg]; longer than 48" [1219mm] = 600 lb. [273kg])
- **Choice of Finishes:** Super Adjustable 2™ Super Erecta shelving is available in a variety of finishes: Super Erecta Brite and chrome-plated for dry storage; Metroseal 3™ with antimicrobial product protection and stainless steel for corrosive environments; and attractive black epoxy for merchandising applications.



Dry Storage — Chrome or Super Erecta Brite™



All Environments — Metroseal 3™ with *Microban® Antimicrobial Product Protection



Mobile Stem Caster Cart



Mobile Dolly Truck

Super Adjustable 2™ Advantage . . .

Easily reposition Super Adjustable 2™ shelves during initial assembly to increase storage capacity by as much as 25%.



Corner Release System

*MICROBAN® and the MICROBAN® symbol are registered trademarks of the Microban Products Company, Huntersville, NC.



InterMetro Industries Corporation
North Washington Street
Wilkes-Barre, PA 18705
www.metro.com



10.01A



SUPER ADJUSTABLE 2™ SUPER ERECTA SHELF® WIRE SHELVING

Dimensions

Super Adjustable 2™ Super Erecta Wire Shelving

Cat. No. Super Erecta Brite	Cat. No. Chrome	Cat. No. Metroseal 3	Cat. No. Stainless	Cat. No. Black	Shelf Width/Length (in.) (mm)	Approx. Pkd. Wt. (lbs.) (kg)
A1424BR	A1424NC	A1424NK3	A1424NS	A1424NBL	14x24 355x610	6 2.7
A1430BR	A1430NC	A1430NK3	A1430NS	A1430NBL	14x30 355x760	7 3.2
A1436BR	A1436NC	A1436NK3	A1436NS	A1436NBL	14x36 355x914	8 3.6
A1442BR	A1442NC	A1442NK3	A1442NS	A1442NBL	14x42 355x1066	9 1/2 4.3
A1448BR	A1448NC	A1448NK3	A1448NS	A1448NBL	14x48 355x1219	10 1/2 4.7
A1460BR	A1460NC	A1460NK3	A1460NS	A1460NBL	14x60 355x1524	14 6.3
A1472BR	A1472NC	A1472NK3	A1472NS	A1472NBL	14x72 355x1825	17 7.7
A1824BR	A1824NC	A1824NK3	A1824NS	A1824NBL	18x24 457x610	7 3.2
A1830BR	A1830NC	A1830NK3	A1830NS	A1830NBL	18x30 457x760	8 3.6
A1836BR	A1836NC	A1836NK3	A1836NS	A1836NBL	18x36 457x914	9 1/2 4.3
A1842BR	A1842NC	A1842NK3	A1842NS	A1842NBL	18x42 457x1066	11 5.0
A1848BR	A1848NC	A1848NK3	A1848NS	A1848NBL	18x48 457x1219	12 5.4
A1854BR	A1854NC	A1854NK3	A1854NS	A1854NBL	18x54 457x1370	14 1/2 6.6
A1860BR	A1860NC	A1860NK3	A1860NS	A1860NBL	18x60 457x1524	17 7.7
A1872BR	A1872NC	A1872NK3	A1872NS	A1872NBL	18x72 457x1825	20 9.1
A2124BR	A2124NC	A2124NK3	A2124NS	A2124NBL	21x24 530x610	8 3.6
A2130BR	A2130NC	A2130NK3	A2130NS	A2130NBL	21x30 530x760	9 4.1
A2136BR	A2136NC	A2136NK3	A2136NS	A2136NBL	21x36 530x914	11 5.0
A2142BR	A2142NC	A2142NK3	A2142NS	A2142NBL	21x42 530x1066	12 5.4
A2148BR	A2148NC	A2148NK3	A2148NS	A2148NBL	21x48 530x1219	14 6.4
A2154BR	A2154NC	A2154NK3	A2154NS	A2154NBL	21x54 530x1370	16 7.3
A2160BR	A2160NC	A2160NK3	A2160NS	A2160NBL	21x60 530x1524	18 8.2
A2172BR	A2172NC	A2172NK3	A2172NS	A2172NBL	21x72 530x1825	24 10.9
A2424BR	A2424NC	A2424NK3	A2424NS	A2424NBL	24x24 610x610	9 4.1
A2430BR	A2430NC	A2430NK3	A2430NS	A2430NBL	24x30 610x760	11 5.0
A2436BR	A2436NC	A2436NK3	A2436NS	A2436NBL	24x36 610x914	13 5.9
A2442BR	A2442NC	A2442NK3	A2442NS	A2442NBL	24x42 610x1066	15 6.8
A2448BR	A2448NC	A2448NK3	A2448NS	A2448NBL	24x48 610x1219	16 7.3
A2454BR	A2454NC	A2454NK3	A2454NS	A2454NBL	24x54 610x1370	18 8.6
A2460BR	A2460NC	A2460NK3	A2460NS	A2460NBL	24x60 610x1524	21 9.5
A2472BR	A2472NC	A2472NK3	A2472NS	A2472NBL	24x72 610x1825	26 11.8
	A3036NC	A3036NK3	A3036NS		30x36 760x914	15 6.8
	A3048NC	A3048NK3	A3048NS		30x48 760x1219	21 9.5
	A3060NC	A3060NK3	A3060NS		30x60 760x1524	26 1/2 11.8
	A3072NC	A3072NK3	A3072NS		30x72 760x1829	31 14.0
	A3636NC	A3636NK3	A3636NS		36x36 910x914	18 8.2
	A3648NC	A3648NK3	A3648NS		36x48 910x1219	23 10.4
	A3660NC	A3660NK3	A3660NS		36x60 910x1524	29 13.1
	A3672NC	A3672NK3	A3672NS		36x72 910x1829	34 1/2 15.4

NOTE: MICROBAN® protects the Metroseal 3 coating from bacteria, mold, mildew and fungi that cause odors, stains and product degradation. For Metroseal 3 shelving information see sheet #10.10A.

SUPER ADJUSTABLE 2™ SUPER ERECTA SHELF®
Adjustable Wire Shelving



Replacement Parts

Each kit includes components for one original Super Adjustable or Super Adjustable 2 shelf; (4) wedges, (4) sleeves, (4) shelf releases.
Cat. No. SAKITA2

SiteSelect™ Posts

STATIONARY					MOBILE†					Approx. Pkd. Wt. (lbs.) (kg)
Height* (in.) (mm)	Cat. No. Plated	Cat. No. Metroseal 3	Cat. No. Stainless	Cat. No. Black	Height* (in.) (mm)	Cat. No. Plated	Cat. No. Metroseal 3	Cat. No. Stainless	Cat. No. Black	
7 1/2	191	7P		7PBL						1/2 0.3
14 1/2	370	13P	13PK3	13PS 13PBL						1 0.5
27 1/2	700	27P		27PS 27PBL	27 1/2	699	27UP		27UPS	1 3/4 0.75
34 1/2	875	33P	33PK3	33PS 33PBL	33 7/8	861	33UP	33UPK3	33UPS 33UPBL	2 0.9
54 9/16	1385	54P	54PK3	54PS 54PBL	54	1370	54UP	54UPK3	54UPS 54UPBL	3 1.4
62 9/16	1590	63P	63PK3	63PS 63PBL	62	1575	63UP	63UPK3	63UPS 63UPBL	3 1/2 1.6
					70	1778		70UPK3		3 3/4 1.7
74 5/8	1895	74P	74PK3	74PS 74PBL	74	1880	74UP	74UPK3	74UPS 74UPBL	4 1.8
86 5/8	2200	86P	86PK3	86PS 86PBL	86	2185	86UP	86UPK3	86UPS 86UPBL	4.5 2.0
96 5/8	2454	**96P								1/2 2.5

*Height includes leveling bolt and cap.
 **96P should not be used in units less than 24" (610mm) deep. Consult Metro Engineering for alternate recommendations.
 † Post lengths to be specified as cut to a round number, ie: 74P cut to 69"... This will result in an overall post height with adjustment of 69 9/16 to 69 7/8.
 ‡ Mobile posts come without leveling bolt assembly to accommodate stem casters.

Important: When ordering by components remember that for maximum stability, units should be kept as wide and low as possible.

All Metro Catalog Sheets are available on our Web Site: www.metro.com



InterMetro Industries Corporation
 North Washington Street, Wilkes-Barre, PA 18705
 Phone: 570-825-2741 • Fax: 570-825-2852
 For Product Information Call: 1-800-433-2232

L02-006A
 Printed in U.S.A. Rev. 1/06
 Information and specifications are subject to change without notice. Please confirm at time of order.
 Copyright © 2006 InterMetro Industries Corp.